

The scoreboard interface is divided into three main sections: a Red team scoreboard on the left, a central control area, and a Yellow team scoreboard on the right.

- Red Team Scoreboard (Left):** A vertical stack of five score buttons labeled +4, +3, +2, +1, and -1. To the right of the +3 button is an "Edit Score" button. To the right of the +2 button is an "Edit Time Out" button. Below the +2 button is a "Time Out -1" button.
- Yellow Team Scoreboard (Right):** A vertical stack of five score buttons labeled +4, +3, +2, +1, and -1. To the left of the +3 button is an "Edit Score" button. To the left of the +2 button is an "Edit Time Out" button. Below the +2 button is a "Time Out -1" button.
- Central Control Area:**
  - Top row: "Up Down" (blue), "Edit Time" (red), "Reset Time" (blue), "Time of Day" (blue).
  - Second row: "Period +1" (blue), "BALL POSS." (blue with a double-headed arrow).
  - Third row: "CLEAR KEY" (red), "CLEAR POSS." (red).
  - Bottom row: "EDIT KEY" (red), "RESET KEY" (blue), "RESET POSS." (blue), "EDIT POSS." (red).

**Whirlyball Scoreboard**

This is an identical copy of the Whirlyball Scoreboard interface described above, featuring the same layout of score buttons, edit functions, and central control buttons for Red and Yellow teams.

**Whirlyball Scoreboard**